

mation about the features related to controlling access to a Node's Endpoint Clusters ("Targets" hereafter) from other Nodes.

See [Section 9.10.4.2.1, "Managed Device Feature Usage Restrictions"](#) for limitations on the use of access restrictions.

9.10.7. Error handling

Administrators SHALL use regular actions to administer the Access Control Cluster (by reading and writing entries in the list). Administrators SHOULD take care to use DataVersion conditional writes when administering the list or its contents.

The Access Control Cluster SHALL fail to write, and return an appropriate error, if an attempt is made to create or update an Access Control Entry or Access Control Extension such that it would have invalid contents.

For example, the following Access Control Entry conditions will result in an error of CONSTRAINT_ERROR:

- Privilege enum value invalid
- AuthMode enum value invalid
- AuthMode is PASE (reserved for future use)
- Subjects element invalid
 - e.g. illegal CAT with CASE AuthMode
- Targets element invalid
 - e.g. no field present
 - e.g. both Endpoint and DeviceType fields present
- Field combinations invalid
 - e.g. Administer Privilege with Group AuthMode

For example, the following Access Control Extension conditions will result in an error of CONSTRAINT_ERROR:

- There is an attempt to add more than 1 entry associated with the given [accessing fabric index](#) in the extension list
- Data value exceeds max length
- Data value not valid [TLV-encoded](#) data

The Access Control Cluster MAY fail to write, and return a RESOURCE_EXHAUSTED error, if an attempt is made to create or update an entry or extension such that storage is exhausted.

9.10.8. Commands