

AdminNodeID Field

The Node ID of the Administrator that made the change, if the change occurred via a CASE session.

Exactly one of AdminNodeID and AdminPasscodeID SHALL be set, depending on whether the change occurred via a CASE or PASE session; the other SHALL be null.

AdminPasscodeID Field

The Passcode ID of the Administrator that made the change, if the change occurred via a PASE session. Non-zero values are reserved for future use (see [PasscodeId generation in PBKDFParamRequest](#)).

Exactly one of AdminNodeID and AdminPasscodeID SHALL be set, depending on whether the change occurred via a CASE or PASE session; the other SHALL be null.

ChangeType Field

The [type of change](#) as appropriate.

LatestValue Field

The latest value of the changed [entry](#).

This field SHOULD be set if resources are adequate for it; otherwise it SHALL be set to NULL if resources are scarce.

9.10.9.2. AccessControlExtensionChanged Event

The server SHALL generate AccessControlExtensionChanged events whenever its [extension](#) attribute data is changed by an Administrator.

- Each added extension SHALL generate an event with ChangeType Added.
- Each changed extension SHALL generate an event with ChangeType Changed.
- Each removed extension SHALL generate an event with ChangeType Removed.

Access Modifier: Fabric-Sensitive						
ID	Name	Type	Constraint	Quality	Fallback	Conformance
1	AdminNodeID	node-id	desc	X		M
2	AdminPasscodeID	uint16	desc	X		M
3	ChangeType	ChangeTypeEnum	all			M
4	LatestValue	AccessControlExtensionStruct	all	X		M