

9.13.7.1. Leave Event

The Leave event SHOULD be generated by the bridge when it detects that the associated device has left the non-Matter network.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	FabricIndex					X

NOTE

The **FabricIndex** field has the **X** conformance, indicating it SHALL NOT be present. This event, in the context of Bridged Device Basic Information cluster, has no usable fields, but the original Basic Information cluster's field definition is kept for completeness.

9.13.7.2. ReachableChanged Event

This event SHALL be generated when there is a change in the Reachable attribute. Its purpose is to provide an indication towards interested parties that the reachability of a bridged device has changed over its native connectivity technology, so they MAY take appropriate action.

After (re)start of a bridge this event MAY be generated.

9.13.7.3. ActiveChanged Event

This event (when supported) SHALL be generated the next time a bridged device becomes active after a KeepActive command is received.

See [KeepActive](#) for more details.

The data of this event SHALL contain the following information:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	PromisedActiveDuration	uint32	desc			M

PromisedActiveDuration Field

This field SHALL indicate the minimum duration, in milliseconds, that the bridged device will remain active after receiving the initial request from the [KeepActive](#) processing steps.

If the bridged device is a Matter Intermittently Connected Device, PromisedActiveDuration SHALL be set to the PromisedActiveDuration value returned in the [StayActiveResponse](#) command.

If the bridged device is not a Matter Intermittently Connected Device, the implementation of this is best-effort since it may interact with non-native protocol.