

ID	Name	Direction	Response	Access	Conformance
0x07	ResumeAction	client ⇒ server	Y	O	desc
0x08	EnableAction	client ⇒ server	Y	O	desc
0x09	EnableAction- WithDuration	client ⇒ server	Y	O	desc
0x0A	DisableAction	client ⇒ server	Y	O	desc
0x0B	DisableAction- WithDuration	client ⇒ server	Y	O	desc

Conformance: a server SHALL support a command when it is listed in the SupportedCommands data field of one or more actions listed in the ActionList provided by the server.

Some general requirements and data fields for all the commands:

- The ActionID data field SHALL indicate the action identifier. If there is no entry in the ActionList holding the same action identifier, a response SHALL be generated with the StatusCode NOT_FOUND.
- The InvokeID data field MAY be provided by the client when invoking a command. When this value is provided, the server SHALL generate a [StateChanged](#) event when the action changes to a new state or an [ActionFailed](#) event when execution of the action fails; in the data of such events, the value of the InvokeID data field from the invoke will be provided, so that the client can relate the event back to the corresponding command. It is up to the client to determine which value is provided in InvokeID. When sending multiple commands for the same action, with different InvokeID, the server SHALL provide in the event the InvokeID value from the most recent command for a particular ActionID.
- If the command refers to an action which currently is not in a state where the command applies, a response SHALL be generated with the StatusCode INVALID_COMMAND.
- Actions are typically mapped to state changes of the involved endpoints. Those endpoints can also be controlled with commands from other clusters, controlled by other nodes and impacted by non-Matter interactions (e.g. local controls). Such other interactions can cause the state of the endpoints to differ from the results of the command which triggered the action. A client interested in such changes can use the InvokeID data field (see above) to receive events StateChanged and ActionFailed for feedback for such cases.

9.14.6.1. InstantAction Command

This command is used to trigger an instantaneous action.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ActionID	uint16	all			M
1	InvokeID	uint32	all			O

This command triggers an action (state change) on the involved endpoints, in a "fire and forget" manner. Afterwards, the action's state SHALL be Inactive.