

- The [Message Counter](#) value SHALL be the current value of the [global unencrypted message counter](#).
- The [DSIZ](#) field of the [Message Flags](#) SHALL be set to 0.

Protocol Header Field

The Check-In message will have the following values for the protocol header field :

- The [Initiator flag](#) field SHALL be set to 1.
- The [Reliability flag](#) field SHALL be set to 0.
- The [SX flag](#) field SHALL be set to 0.
- The [Vendor Flag](#) field SHALL be set to 0.

Protocol Id and Opcode

The ICD Check-In message SHALL have [secure channel](#) protocol ID. The ICD Check-In message SHALL have the [ICD Check-In message](#) protocol opcode.

Sending Check-In Message Steps

When sending an ICD Check-In message, the server SHALL respect the following requirements:

1. The server SHALL NOT send more than one Check-In message with a given [ICD counter value](#) to the same [RegisteredClient CheckInNodeID](#).
2. The server SHALL follow the [encryption process](#) of the Check-In Protocol.
3. The server SHALL configure the Matter header as defined in [message format](#) section.

The server MAY try to resolve the IP address and the port of the [CheckInNodeID](#) each time the server needs to send a Check-In message to a [RegisteredClient CheckInNodeID](#).

9.15.1.4. User Active Mode Trigger

Since ICDs are not immediately responsive, they require a means to render them available for communication for user initiated use cases. Some of the user initiated use cases are:

- Opening a new commissioning window to add another administrator.
- Reconfiguration of an existing fabric (e.g. IPKs, NOC rotation, ACL changes).
- Reconfiguration of cluster functionality (e.g. ICD Management, Bindings, Groups, Scenes).
- Removal of a device from a fabric.
- Changes to the device's settings.

An ICD that requires user initiated use cases SHALL provide an Active Mode Trigger as a way for a user to put the device into active mode and make it responsive to controller communication. The [UserActiveModeTrigger](#) feature in the [ICD Management cluster](#) indicates whether a particular device implements an active mode trigger.