

UniqueLocationID Field

This field SHALL indicate a unique identifier for a specific Ecosystem Information Cluster server instance representing the location independent of its LocationDescriptor field.

UniqueLocationID can be used by the client to determine if the change is a relocation of the device or just a renaming of the location.

No guarantees are given for consistency of the ID between server instances. The same location may be represented by different IDs on different Ecosystem Information Cluster server instances, so only the history from a single server instance should be considered when evaluating a change.

UniqueLocationID SHALL be changed when the LocationDescriptor changes from one existing location to another location as a result of an external interaction. (For example, the user changes the location assignment.)

UniqueLocationID SHALL NOT be changed when the LocationDescriptor changes name, but still represents the same location. (For example, the user renames a room.)

UniqueLocationID SHALL be changed when LocationDescriptor changes as a result of another Ecosystem Information Cluster server instance changing and the UniqueLocationID on the remote server instance also changes.

UniqueLocationID SHALL NOT be changed when LocationDescriptor changes as a result of another Ecosystem Information Cluster server instance changing and the UniqueLocationID on the remote server instance does not change.

LocationDescriptor Field

This field SHALL indicate the location (e.g. living room, driveway) and associated metadata that is provided externally if the user consents. (For example, provided by the user in an ecosystem specific interface.)

"Location" in this context is typically used by the user's grouping into rooms, areas or other logical groupings of how devices are used. So a device might be part of multiple such "Locations"s.

LocationDescriptorLastEdit Field

This field SHALL indicate the timestamp of when the LocationDescriptor was last modified.

9.17.5. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	DeviceDirectory	list[EcosystemDeviceStruct]		N		R M F	M
0x0001	LocationDirectory	list[EcosystemLocationStruct]		N		R M F	M