




Figure 90. Read message with client-side error flow

10.2.4.4. Write (Success)




Figure 91. Write message flow

10.2.4.5. Write (Server Error)




Figure 92. Write message with server-side error flow

10.2.4.6. Subscribe (Success)