

tified. The value of this attribute SHALL be one of the valid values listed in [Section 7.1.1, “Revision History”](#).

11.1.5.2. VendorName Attribute

This attribute SHALL specify a human readable (displayable) name of the vendor for the Node.

11.1.5.3. VendorID Attribute

This attribute SHALL specify the [Vendor ID](#).

11.1.5.4. ProductName Attribute

This attribute SHALL specify a human readable (displayable) name of the model for the Node such as the model number (or other identifier) assigned by the vendor.

11.1.5.5. ProductID Attribute

This attribute SHALL specify the [Product ID](#) assigned by the vendor that is unique to the specific product of the Node.

11.1.5.6. NodeLabel Attribute

This attribute SHALL represent a user defined name for the Node. This attribute SHOULD be set during initial commissioning and MAY be updated by further reconfigurations.

11.1.5.7. Location Attribute

This attribute SHALL be an ISO 3166-1 alpha-2 code to represent the country, dependent territory, or special area of geographic interest in which the Node is located at the time of the attribute being set. This attribute SHALL be set during initial commissioning (unless already set) and MAY be updated by further reconfigurations. This attribute MAY affect some regulatory aspects of the Node's operation, such as radio transmission power levels in given spectrum allocation bands if technologies where this is applicable are used. The Location's region code SHALL be interpreted in a case-insensitive manner. If the Node cannot understand the location code with which it was configured, or the location code has not yet been configured, it SHALL configure itself in a region-agnostic manner as determined by the vendor, avoiding region-specific assumptions as much as is practical. The special value XX SHALL indicate that region-agnostic mode is used.

11.1.5.8. HardwareVersion Attribute

This attribute SHALL specify the version number of the hardware of the Node. The meaning of its value, and the versioning scheme, are vendor defined.

11.1.5.9. HardwareVersionString Attribute

This attribute SHALL specify the version number of the hardware of the Node. The meaning of its value, and the versioning scheme, are vendor defined. The HardwareVersionString attribute SHALL be used to provide a more user-friendly value than that represented by the [HardwareVersion](#) attribute.