

interested in monitoring changes in active faults MAY subscribe to this attribute, or they MAY subscribe to [WiredFaultChange](#).

#### **11.7.7.12. BatVoltage Attribute**

This attribute SHALL indicate the currently measured output voltage of the battery in mV (millivolts). A value of NULL SHALL indicate the Node is currently unable to assess the value.

#### **11.7.7.13. BatPercentRemaining Attribute**

This attribute SHALL indicate the estimated percentage of battery charge remaining until the battery will no longer be able to provide power to the Node. Values are expressed in half percent units, ranging from 0 to 200. E.g. a value of 48 is equivalent to 24%. A value of NULL SHALL indicate the Node is currently unable to assess the value.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once every 10 seconds, or
- When it changes from null to any other value and vice versa.

Since reporting consumes power, devices SHOULD be careful not to over-report.

#### **11.7.7.14. BatTimeRemaining Attribute**

This attribute SHALL indicate the estimated time in seconds before the battery will no longer be able to provide power to the Node. A value of NULL SHALL indicate the Node is currently unable to assess the value.

Changes to this attribute SHALL only be marked as reportable in the following cases:

- At most once every 10 seconds, or
- When it changes from null to any other value and vice versa.

Since reporting consumes power, devices SHOULD be careful not to over-report.

#### **11.7.7.15. BatChargeLevel Attribute**

This attribute SHALL indicate a coarse ranking of the charge level of the battery, used to indicate when intervention is required as specified in [BatChargeLevelEnum](#).

#### **11.7.7.16. BatReplacementNeeded Attribute**

This attribute SHALL indicate if the battery needs to be replaced. Replacement MAY be simple routine maintenance, such as with a single use, non-rechargeable cell. Replacement, however, MAY also indicate end of life, or serious fault with a rechargeable or even non-replaceable cell.

#### **11.7.7.17. BatReplaceability Attribute**

This attribute SHALL indicate the replaceability of the battery as specified in [BatReplaceabilityEnum](#).