

After Commissioning or reconfiguration ends successfully, because of successful invocation of the [CommissioningComplete](#) command, the cluster server SHOULD NOT attempt to change connected network until connectivity failure or restart occurs, but rather it SHALL commit the tentative configuration to persistent storage so that it is usable the next time connectivity establishment is needed.

After Commissioning or reconfiguration ends in failure due to expiry of the Fail-Safe timer, the Node SHALL revert to the network configuration present prior to the Fail-Safe timer being armed.

Because it is possible that multiple network configurations being present could successfully result in an established operational network connection, but only some of these configurations actually have the desired reachability by Administrators on certain fabrics, the following precautions SHOULD be taken to avoid a situation where a Node forever dwells on a network with successful connectivity, but no reachable peers:

- Commissioners and Administrators MAY notify users if multiple independent configurations exist that could cause an alternate configuration to make the device unreachable for reconfiguration by Nodes on the current client's fabric in the future.
- Commissioners and Administrators SHOULD avoid configuring Nodes in ways where it may be ambiguous to end-users which final network configuration will take place.
- Cluster servers on devices with no user interface to express current network configuration to an end-user SHOULD be configured to only support a single entry in the [Networks attribute](#).
- Upon discovering that a user is desiring to configure a Network in a way that would change the set of configured networks, and there are multiple fabrics configured in the [Fabrics](#) attribute of the [Operational Credentials](#) cluster, the client SHOULD notify the user that some other Administrators on other fabrics MAY fail to reach the Node and report connectivity failures.

11.10. General Commissioning Cluster

This cluster is used to manage basic commissioning lifecycle.

This cluster also represents responsibilities related to commissioning that don't well fit other commissioning clusters, like [Section 11.9, "Network Commissioning Cluster"](#). It also hosts functionalities those other clusters may depend on.

11.10.1. Revision History

The global ClusterRevision attribute value SHALL be the highest revision number in the table below.

Revision	Description
1	Initial revision
2	Add Enhanced Setup Flow