

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0007	TCAcknowledgements	map16	all	N		R A	TC
0x0008	TCAcknowledgementsRequired	bool	all	N	true	R A	TC
0x0009	TCUpdateDeadline	uint32	all	N X		R A	TC
0x000A	RecoveryIdentifier	octstr	8	N	0	R M	P, NR
0x000B	NetworkRecoveryReason	NetworkRecoveryReasonEnum	all	X	null	R M	P, NR
0x000C	IsCommissioningWithoutPower	bool	all		false	R V	P, O

11.10.6.1. Breadcrumb Attribute

This attribute allows for the storage of a client-provided small payload which Administrators and Commissioners MAY write and then subsequently read, to keep track of their own progress. This MAY be used by the Commissioner to avoid repeating already-executed actions upon re-establishing a commissioning link after an error.

On start/restart of the server, such as when a device is power-cycled, this attribute SHALL be reset to zero.

Some commands related to commissioning also have a side-effect of updating or resetting this attribute and this is specified in their respective functional descriptions.

The format of the value within this attribute is unspecified and its value is not otherwise used by the functioning of any cluster, other than being set as a side-effect of commands where this behavior is described.

11.10.6.2. BasicCommissioningInfo Attribute

This attribute SHALL describe critical parameters needed at the beginning of commissioning flow. See [Section 11.10.5.4, “BasicCommissioningInfo”](#) for more information.