

11.10.6.12. NetworkRecoveryReason Attribute

This attribute SHALL contain the primary reason that triggered the Network Recovery flow and its associated advertisements. This attribute SHALL be null when the Node is not undergoing a Network Recovery flow.

11.10.6.13. IsCommissioningWithoutPower Attribute

The server SHALL set this attribute to true if and only if is currently operating on the commissioning channel but cannot operate on the operational channel because it is not powered.

This may happen during NFC-based commissioning, when the commissioning channel is [NFC Transport Layer \(NTL\)](#), because it can harvest energy from NFC to operate. However, such a Commissionee must be powered on to switch to the operational channel.

This attribute is used by the Commissioner as described in step 18 of [Section 5.5, “Commissioning Flows”](#). This attribute is linked to the Commissionee behavior after reception of the [ConnectNetwork Command](#).

11.10.7. Commands

For all client-to-server commands in this cluster, if the client deems that it has timed-out in receiving the corresponding response command to any request, the corresponding step in the commissioning flow SHALL be considered to have failed, with the error handled as described in [Section 5.5.1, “Commissioning Flows Error Handling”](#).

ID	Name	Direction	Response	Access	Conformance
0x00	ArmFailSafe	client ⇒ server	ArmFailSafeResponse	A	M
0x01	ArmFailSafeResponse	client ⇐ server	N		M
0x02	SetRegulatoryConfig	client ⇒ server	SetRegulatoryConfigResponse	A	M
0x03	SetRegulatoryConfigResponse	client ⇐ server	N		M
0x04	CommissioningComplete	client ⇒ server	CommissioningCompleteResponse	A F	M
0x05	CommissioningCompleteResponse	client ⇐ server	N		M
0x06	SetTCAcknowledgements	client ⇒ server	SetTCAcknowledgementsResponse	A	TC