

If the value of EventTrigger received is not supported by the receiving Node, this command SHALL fail with a status code of INVALID_COMMAND.

Otherwise, if the EnableKey value matches the configured internal value for a particular Node, and the EventTrigger value matches a supported test event trigger value, the command SHALL succeed and execute the expected trigger action.

If no specific test event triggers are required to be supported by certification test requirements for the features that a given product will be certified against, this command MAY always fail with the INVALID_COMMAND status, equivalent to the situation of receiving an unknown EventTrigger, for all possible EventTrigger values.

11.12.7.2. TimeSnapshot Command

This command MAY be used by a client to obtain a correlated view of both System Time, and, if currently synchronized and supported, "wall clock time" of the server. This can help clients establish time correlation between their concept of time and the server's concept of time. This is especially useful when processing event histories where some events only contain System Time.

Upon command invocation, the server SHALL respond with a TimeSnapshotResponse.

11.12.7.3. TimeSnapshotResponse Command

This command SHALL be generated in response to a TimeSnapshot command.

When generating this response, all fields SHALL be gathered as close together in time as possible, so that the time jitter between the values is minimized.

If the Time Synchronization cluster is supported by the node, the PosixTimeMs field SHALL NOT be null unless the UTCTime attribute in the Time Synchronization cluster is also null.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0x00	System-TimeMs	systime-ms	all		MS	M
0x01	Posix-TimeMs	posix-ms	all	X	null	M

SystemTimeMs Field

This SHALL indicate the current System Time in milliseconds (type [systime-ms](#)), with the value taken at the time of processing of the TimeSnapshot command that generated this response.

The value SHALL be taken from the same clock which populates the [Timestamp field](#) in events when using System Time for the field.

PosixTimeMs Field

This SHALL indicate the current time in [POSIX Time in milliseconds](#), with the value taken from the same source that could populate the [Timestamp field of events](#). This value SHALL only be null