

11.14.6.17. RouterRoleCount Attribute

This attribute SHALL indicate the number of times the Node entered the OT_DEVICE_ROLE_ROUTER role as specified within the Thread specification. This value SHALL only be reset upon a Node reboot.

11.14.6.18. LeaderRoleCount Attribute

This attribute SHALL indicate the number of times the Node entered the OT_DEVICE_ROLE_LEADER role as specified within the Thread specification. This value SHALL only be reset upon a Node reboot.

11.14.6.19. AttachAttemptCount Attribute

This attribute SHALL indicate the number of attempts that have been made to attach to a Thread network while the Node was detached from all Thread networks. This value SHALL only be reset upon a Node reboot.

11.14.6.20. PartitionIdChangeCount Attribute

This attribute SHALL indicate the number of times that the Thread network that the Node is connected to has changed its Partition ID. This value SHALL only be reset upon a Node reboot.

11.14.6.21. BetterPartitionAttachAttemptCount Attribute

This attribute SHALL indicate the number of times a Node has attempted to attach to a different Thread partition that it has determined is better than the partition it is currently attached to. This value SHALL only be reset upon a Node reboot.

11.14.6.22. ParentChangeCount Attribute

This attribute SHALL indicate the number of times a Node has changed its parent. This value SHALL only be reset upon a Node reboot.

11.14.6.23. TxTotalCount Attribute

This attribute SHALL indicate the total number of unique MAC frame transmission requests. The attribute SHALL only be incremented by 1 for each MAC transmission request regardless of the amount of CCA failures, CSMA-CA attempts, or retransmissions. This value SHALL only be reset upon a Node reboot.

11.14.6.24. TxUnicastCount Attribute

This attribute SHALL indicate the total number of unique unicast MAC frame transmission requests. The attribute SHALL only be incremented by 1 for each unicast MAC transmission request regardless of the amount of CCA failures, CSMA-CA attempts, or retransmissions. This value SHALL only be reset upon a Node reboot.

11.14.6.25. TxBroadcastCount Attribute

This attribute SHALL indicate the total number of unique broadcast MAC frame transmission