

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0002	PacketRx-Count	uint64	all	C	0	R V	PKTCNT
0x0003	PacketTx-Count	uint64	all	C	0	R V	PKTCNT
0x0004	TxEr-rCount	uint64	all	C	0	R V	ERRCNT
0x0005	Collision-Count	uint64	all	C	0	R V	ERRCNT
0x0006	Overrun-Count	uint64	all	C	0	R V	ERRCNT
0x0007	CarrierDetect	bool	all	C X	null	R V	O
0x0008	TimeSin-ceReset	uint64	all	C	0	R V	O

11.16.6.1. PHYRate Attribute

This attribute SHALL indicate the current nominal, usable speed at the top of the physical layer of the Node. A value of null SHALL indicate that the interface is not currently configured or operational.

11.16.6.2. FullDuplex Attribute

This attribute SHALL indicate if the Node is currently utilizing the full-duplex operating mode. A value of null SHALL indicate that the interface is not currently configured or operational.

11.16.6.3. PacketRxCount Attribute

This attribute SHALL indicate the number of packets that have been received on the ethernet network interface. The attribute SHALL be reset to 0 upon a reboot of the Node.

11.16.6.4. PacketTxCount Attribute

This attribute SHALL indicate the number of packets that have been successfully transferred on the ethernet network interface. The attribute SHALL be reset to 0 upon a reboot of the Node.

11.16.6.5. TxErrCount Attribute

This attribute SHALL indicate the number of failed packet transmissions that have occurred on the ethernet network interface. The attribute SHALL be reset to 0 upon a reboot of the Node.

11.16.6.6. CollisionCount Attribute

This attribute SHALL indicate the number of collisions that have occurred while attempting to transmit a packet on the ethernet network interface. The attribute SHALL be reset to 0 upon a