

reboot of the Node.

11.16.6.7. **OverrunCount Attribute**

This attribute SHALL indicate the number of packets dropped either at ingress or egress, due to lack of buffer memory to retain all packets on the ethernet network interface. The attribute SHALL be reset to 0 upon a reboot of the Node.

11.16.6.8. **CarrierDetect Attribute**

This attribute SHALL indicate the value of the Carrier Detect control signal present on the ethernet network interface. A value of null SHALL indicate that the interface is not currently configured or operational.

11.16.6.9. **TimeSinceReset Attribute**

This attribute SHALL indicate the duration of time, in minutes, that it has been since the ethernet network interface has reset for any reason.

11.16.7. **Commands**

ID	Name	Direction	Response	Access	Conformance
0x00	ResetCounts	client ⇒ server	Y	M	PKTCNT ERRCNT

11.16.7.1. **ResetCounts Command**

This command is used to reset the count attributes.

Reception of this command SHALL reset the following attributes to 0:

- [PacketRxCount](#)
- [PacketTxCount](#)
- [TxErrCount](#)
- [CollisionCount](#)
- [OverrunCount](#)

11.17. **Time Synchronization Cluster**

Accurate time is required for a number of reasons, including scheduling, display and validating security materials.

This section describes a mechanism for Nodes to achieve and maintain time synchronization. The Time Synchronization cluster provides attributes for reading a Node’s current time. It also allows Administrators to set current time, time zone and daylight savings time (DST) settings.

The Time Synchronization cluster MAY be present on the [root node endpoint](#), and SHALL NOT be