

ID	Name	Direction	Response	Access	Conformance
0x05	SetDefaultNTP	client ⇒ server	Y	A	NTPC

11.17.9.1. SetUTCTime Command

This command is used to set the UTC time of the node.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	UTCTime	epoch-us	all		0	M
1	Granularity	GranularityEnum	all		NoTime-Granularity	M
2	TimeSource	TimeSourceEnum	all		None	O

This command MAY be issued by Administrator to set the time. If the Commissioner does not have a valid time source, it MAY send a Granularity of NoTimeGranularity.

Upon receipt of this command, the node MAY update its UTCTime attribute to match the time specified in the command, if the stated Granularity and TimeSource are acceptable. The node SHALL update its UTCTime attribute if its current Granularity is NoTimeGranularity.

If the time is updated, the node SHALL also update its Granularity attribute based on the granularity specified in the command and the expected clock drift of the node. This SHOULD normally be one level lower than the stated command Granularity. It SHALL also update its TimeSource attribute to Admin. It SHALL also update its Last Known Good UTC Time as defined in [Section 3.5.6.1, “Last Known Good UTC Time”](#).

If the node updates its UTCTime attribute, it SHALL accept the command with a status code of SUCCESS. If it opts to not update its time, it SHALL fail the command with a cluster specific Status Code of TimeNotAccepted.

UTCTime Field

This field SHALL give the Client’s UTC Time.

Granularity Field

This field SHALL give the Client’s Granularity, as described in [Granularity](#).

TimeSource Field

This field SHALL give the Client’s TimeSource, as described in [TimeSource](#).

11.17.9.2. SetTrustedTimeSource Command

This command is used to set the TrustedTimeSource attribute.

Upon receipt of this command: