

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0005	Current-FabricIndex	uint8			0	R V	M

11.18.5.1. NOCs Attribute

This attribute SHALL contain all NOCs applicable to this Node, encoded as a read-only list of [NOC-Struct](#).

Operational Certificates SHALL be added through the [AddNOC](#) command, and SHALL be removed through the [RemoveFabric](#) command.

Upon Factory Data Reset, this attribute SHALL be set to a default value of an empty list.

The number of entries in this list SHALL match the number of entries in the Fabrics attribute.

11.18.5.2. Fabrics Attribute

This attribute SHALL indicate all fabrics to which this Node is commissioned, encoded as a read-only list of [FabricDescriptorStruct](#). This information MAY be computed directly from the NOCs attribute.

The Fabrics attribute is also known as "the fabric table".

Upon Factory Data Reset, this attribute SHALL be set to a default value of an empty list.

The number of entries in this list SHALL match the number of entries in the NOCs attribute.

11.18.5.3. SupportedFabrics Attribute

This attribute SHALL indicate the number of Fabrics that are supported by the device. This value is fixed for a particular device.

11.18.5.4. CommissionedFabrics Attribute

This attribute SHALL indicate the number of Fabrics to which the device is currently commissioned. This attribute SHALL be equal to the following:

- The number of entries in the NOCs attribute.
- The number of entries in the Fabrics attribute.

Upon Factory Data Reset, this attribute SHALL be set to a default value of 0.

11.18.5.5. TrustedRootCertificates Attribute

This attribute SHALL contain the list of [Trusted Root CA Certificates \(RCAC\)](#) installed on the Node, as octet strings containing their [Matter Certificate Encoding](#) representation.