

The CSRNonce field SHALL be used in the computation of the NOCSR Information. If the CSRNonce is malformed, then this command SHALL fail with an INVALID_COMMAND status code.

If the IsForUpdateNOC field is present and set to true, but the command was received over a [PASE](#) session, the command SHALL fail with an INVALID_COMMAND status code, as it would never be possible to use a resulting subsequent certificate issued from the CSR with the [UpdateNOC](#) command, which is forbidden over [PASE](#) sessions.

If the IsForUpdateNOC field is present and set to true, the internal state of the CSR associated key pair SHALL be tagged as being for a subsequent UpdateNOC, otherwise the internal state of the CSR SHALL be tagged as being for a subsequent AddNOC. See [Section 11.18.6.8, “AddNOC Command”](#) and [Section 11.18.6.9, “UpdateNOC Command”](#) for details about the processing.

If this command is received without an armed fail-safe context (see [Section 11.10.7.2, “ArmFail-Safe”](#)), then this command SHALL fail with a FAILSAFE_REQUIRED status code sent back to the initiator.

If a prior UpdateNOC or AddNOC command was successfully executed within the fail-safe timer period, then this command SHALL fail with a CONSTRAINT_ERROR status code sent back to the initiator.

If the Node Operational Key Pair generated during processing of the [Node Operational CSR Procedure](#) is found to collide with an existing key pair already previously generated and installed, and that check had been executed, then this command SHALL fail with a FAILURE status code sent back to the initiator.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	CSRNonce	octstr	32			M
1	IsForUpdateNOC	bool			false	O

11.18.6.6. CSRResponse Command

This command is used to report the results of the CSRRequest command. This command SHALL be generated in response to a [CSRRequest Command](#).

See [Section 11.18.4.9, “NOCSR Information”](#) for details about the generation of the fields within this response command.

See [Section F.3, “Node Operational CSR Response test vector”](#) for an example computation of a CSR-Response.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NOCSRElements	octstr	max RESP_MAX			M