

PAKEPasscodeVerifier Field

This field SHALL specify an ephemeral PAKE passcode verifier (see [Section 3.10, “Password-Authenticated Key Exchange \(PAKE\)”](#)) computed by the existing Administrator to be used for this commissioning. The field is concatenation of two values ($w0 || L$) SHALL be $(CRYPTO_GROUP_SIZE_BYTES + CRYPTO_PUBLIC_KEY_SIZE_BYTES)$ -octets long as detailed in [Crypto_PAKEValues_Responder](#). It SHALL be derived from an ephemeral passcode (See [PAKE](#)). It SHALL be deleted by the Node at the end of commissioning or expiration of the `OpenCommissioningWindow` command, and SHALL be deleted by the existing Administrator after sending it to the Node(s).

Discriminator Field

This field SHALL be used by the Node as the long discriminator for DNS-SD advertisement (see [Section 4.3.1.5, “TXT key for discriminator \(D\)”](#)) for discovery by the new Administrator. The new Administrator can find and filter DNS-SD records by long discriminator to locate and initiate commissioning with the appropriate Node.

Iterations Field

This field SHALL be used by the Node as the PAKE iteration count associated with the ephemeral PAKE passcode verifier to be used for this commissioning, which SHALL be sent by the Node to the new Administrator’s software as response to the [Section 4.14.1.2.3, “PBKDFParamRequest”](#) during PASE negotiation. The permitted range of values SHALL match the range specified in [Section 3.9, “Password-Based Key Derivation Function \(PBKDF\)”](#), within the definition of the `Crypto_PBKDFParameterSet`.

Salt Field

This field SHALL be used by the Node as the PAKE Salt associated with the ephemeral PAKE passcode verifier to be used for this commissioning, which SHALL be sent by the Node to the new Administrator’s software as response to the [Section 4.14.1.2.3, “PBKDFParamRequest”](#) during PASE negotiation. The constraints on the value SHALL match those specified in [Section 3.9, “Password-Based Key Derivation Function \(PBKDF\)”](#), within the definition of the `Crypto_PBKDFParameterSet`.

When a Node receives the [Section 11.19.8.1, “OpenCommissioningWindow”](#) command, it SHALL begin advertising on DNS-SD as described in [Section 4.3.1, “Commissionable Node Discovery”](#) and for a time period as described in [Section 11.19.8.1.1, “CommissioningTimeout”](#).

When the command is received by a ICD, it SHALL enter into [active mode](#). The ICD SHALL remain in Active Mode as long as one of these conditions is met:

- A commissioning window is open.
- There is an armed [fail-safe timer](#).

11.19.8.2. OpenBasicCommissioningWindow Command

This command MAY be used by a current Administrator to instruct a Node to go into commissioning mode, if the node supports the [Basic Commissioning Method](#). The [Basic Commissioning Method](#) specifies a window of time during which an already commissioned Node accepts PASE sessions. The current Administrator SHALL specify a timeout value for the duration of the `OpenBasicCommis-`