

sioningWindow command.

If a commissioning window is already currently open, this command SHALL fail with a cluster specific status code of Busy.

If the [fail-safe timer](#) is currently armed, this command SHALL fail with a cluster specific status code of Busy, since it is likely that concurrent commissioning operations from multiple separate Commissioners are about to take place.

In case of any other parameter error, this command SHALL fail with a status code of COMMAND_INVALID.

The commissioning into a new Fabric completes when the Node successfully receives a [Section 11.10.7.6, “CommissioningComplete”](#) command, see [Section 5.5, “Commissioning Flows”](#). The new Administrator SHALL discover the Node on the IP network using DNS-based Service Discovery (DNS-SD) for commissioning.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Commissioning-Timeout	uint16	desc			M

CommissioningTimeout Field

This field SHALL specify the time in seconds during which commissioning session establishment is allowed by the Node. This timeout SHALL follow guidance as specified in the initial [Section 5.4.2.3, “Announcement Duration”](#).

When a Node receives the [Section 11.19.8.2, “OpenBasicCommissioningWindow”](#) command, it SHALL begin advertising on DNS-SD as described in [Section 4.3.1, “Commissionable Node Discovery”](#) and for a time period as described in [Section 11.19.8.2.1, “CommissioningTimeout”](#). When the command is received by a [ICD](#), it SHALL enter into [active mode](#). The [ICD](#) SHALL remain in Active Mode as long as one of these conditions is met:

- A commissioning window is open.
- There is an armed [fail-safe timer](#).

11.19.8.3. RevokeCommissioning Command

This command is used by a current Administrator to instruct a Node to revoke any active [Section 11.19.8.1, “OpenCommissioningWindow”](#) or [Section 11.19.8.2, “OpenBasicCommissioningWindow”](#) command. This is an idempotent command and the Node SHALL (for ECM) delete the temporary PAKEPasscodeVerifier and associated data, terminate any open PASE sessions or sessions in the process of being established, and stop publishing the DNS-SD record associated with the [Section 11.19.8.1, “OpenCommissioningWindow”](#) or [Section 11.19.8.2, “OpenBasicCommissioningWindow”](#) command, see [Section 4.3.1, “Commissionable Node Discovery”](#).