

- **UNKNOWN**: Internal error beyond the usual error handling.

If any such **StatusReport** message is received, or any other unexpected **StatusReport** is received, the receiving peer SHALL terminate its processing of the transfer and invalidate the exchange.

11.22.4. Security and Transport Constraints

In order to maintain data-in-transit confidentiality, and ensure authenticated message flows, the BDX protocol SHALL only be executed over **PASE** or **CASE** encrypted session. This is enforced by the fact that the only messages allowed to be transmitted without message security are the actual PASE and CASE session establishment messages.

The BDX protocol MAY be carried over any supported Matter messaging transport, such as BTP, **PAFTP**, **NTL**, TCP or MRP, as long as the messages appear in a PASE or CASE session.

Furthermore, the BDX protocol relies on transport-level reliability. Therefore, BDX SHALL always be used over reliable transports. For example, usage with Matter messaging over UDP without MRP reliability, that is, without using the **R Flag** in the **Exchange Flags**, would prevent the necessary reliability.

NOTE

Since using BDX is likely to be used to transfer a considerable amount of data which will take some time, it might not be realistic to use it over **NTL** since it requires steady close proximity between both ends.

11.22.5. Transfer Management Messages

11.22.5.1. **SendInit** and **ReceiveInit** Messages

A **SendInit** message is sent by an Initiator to propose a BDX Transfer session where the Initiator wants to be a Sender and deliver information to another node.

A **ReceiveInit** message is sent by an Initiator to propose a BDX Transfer session where the Initiator wants to be a Receiver and obtain information from another node.

Any BDX transfer exchange begins with one of these two messages.

Both **SendInit** and **ReceiveInit** initiate a negotiation for a number of parameters:

- the Initiator (sender of the message) proposes the transfer parameters and the block size;
- the Responder (receiver of the message) responds with a set of parameters compatible with the Initiator's proposal, according to the Responder's subset of capabilities in common with the Initiator.

The Responder SHALL indicate all the supported modes of operation applicable to the session by replying, upon success, with **SendAccept** (in response to **SendInit**) or **ReceiveAccept** (in response to **ReceiveInit**).

The parameters in the **SendAccept/ReceiveAccept** message SHALL be used in the transfer. If those parameters are unacceptable to the Initiator, it SHALL abort the transfer with an appropriate error