

Value	Name	Summary	Conformance	Description
1	provisional	provisional	M	used for a SoftwareVersion when going into certification testing (These might or might not be placed in DCL, depending on the Connectivity Standards Alliance policy and procedures)
2	certified	certified	M	used for a SoftwareVersion which has been certified
3	revoked	revoked	M	used for a SoftwareVersion which has been revoked

The values 0 through 2 SHALL correspond to the values 0 through 2 used in [certification_type](#) in the [Certification Declaration](#).

11.23.8.3. CDCertificateID

This field SHALL have the Connectivity Standards Alliance certification's certificate ID for the Certification that applies to this record. The value of this field is used in the [Certification Declaration](#)'s [certificate_id](#) field (see [Certification Elements TLV structure](#)) for products using the [VendorID](#), [ProductID](#) and [SoftwareVersion](#) in this schema entry.

11.23.8.4. SchemaVersion

The SchemaVersion field value history for this schema is provided below:

Version	Description
0	Initial Release

11.23.9. Device Attestation PKI Revocation Distribution Points Schema

The Device Attestation PKI revocation distribution points are used to identify the URL where PAAs and PAIs provide revocation information for PAIs and DACs, respectively.

See [Section 6.2, "Device Attestation"](#) for more details on the PKI elements discussed in this subsection (e.g. PAA, PAI, DAC).