

11.24.4.6. Making a Node a Group Controller

In this example of an On/Off Light Switch controlling a group, Node N's Endpoint E (On/Off Light Switch) should control Group G with Group Key Set K:

1. Make sure Node N is in Group G by calling [AddGroupIDToEndpointForNode](#) command with arguments N, E, and G.
2. Add a binding to Endpoint E on Node N by calling [AddBindingToEndpointForNode](#) command with arguments N, E, and the desired Binding.

11.24.4.7. Adding a Joint Fabric Administrator Node to a Fabric

When a Node is a Joint Fabric Administrator, its Group membership does not need to be managed by the Datastore since it has the ability to monitor the Datastore and issue operational certs for its own Administrator Nodes at any time. As a result, rather than adding Joint Fabric Administrator Nodes to the regular NodeList attribute via the [AddPendingNode](#) command, these Nodes SHALL be added to the AdminList via the [AddAdmin](#) command.

It's important to explicitly track the vendor ID of an [Joint Fabric](#) Administrator so that the [Joint Fabric](#) Administrator controlling the Root Operational Cert for the fabric can sign intermediate certificates which can be used by an [Joint Fabric](#) Administrator to issue operational certificates.

11.24.4.8. Adding/Updating/Removing a Group

When adding a group, a client must create the group information entry before adding membership associations between the Node and the Group.

Adding a Group

Add Group Key Set Entry (when applicable) using the [AddKeySet](#) command, followed by Group Information Entry using the [AddGroup](#) command.

Updating a Group

If the GroupKeySetID is changing, update the Group Key Set Entry using the [UpdateKeySet](#) command. Update the Group Information Entry using the [UpdateGroup](#) command. KeySet and Group updates performed using these commands will cause the Datastore to attempt to update all Node members of the group with these changes. Any Node changes that do not complete (for example, if the Node is unreachable) will result in **Pending** status on the data in the Node Information Entry.

Removing a Group

Remove the Group Information Entry using the [UpdateGroup](#) command. This command will fail if the Group is in use (and not with **PendingDelete** Status) by any Nodes.

If the GroupKeySetID is set, remove the Group Key Set Entry using the [RemoveKeySet](#) command. This command will fail if this KeySet is in use by any Groups.

11.24.4.9. Adding/Removing access privileges for a Controller

In order to ensure a consistent approach to access control by Administrators on a [Joint Fabric](#), [Joint](#)