

11.24.7.10. AddPendingNode Command

The command SHALL be used to add a node to the [Joint Fabric](#) Datastore Cluster of the accessing fabric.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all			M
1	Friendly-Name	string	max 32			M

NodeID represents the node to be added to the [Joint Fabric](#) Datastore Cluster.

Upon receipt of this command, the Datastore SHALL:

1. Update CommissioningStatusEntry of the Node Information Entry with the given NodeID to **Pending**.

If a Node Information Entry exists for the given NodeID, this command SHALL return INVALID_-CONSTRAINT.

11.24.7.11. RefreshNode Command

The command SHALL be used to request that Datastore information relating to a Node of the accessing fabric is refreshed.

The data for this command is as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	NodeID	node-id	all			M

Upon receipt of this command, the Datastore SHALL:

1. Confirm that a Node Information Entry exists for the given NodeID, and if not, return NOT_FOUND.
2. Update the CommissioningStatusEntry for the Node Information Entry to **Pending**.
3. Ensure the Endpoint List for the Node Information Entry with the given NodeID matches Endpoint list on the given Node. This involves the following steps:
 - a. Read the PartsList of the Descriptor cluster from the Node.
 - b. For each Endpoint Information Entry in the Endpoint List of the Node Information Entry that does not match an Endpoint ID in the PartsList, remove the Endpoint Information Entry.
 - c. For each Endpoint Information Entry in the Endpoint List of the Node Information Entry that matches an Endpoint ID in the PartsList:
 - i. Check that each entry in Node's Group List occurs in the GroupIDList of the Endpoint