

ID	Name	Type	Constraint	Quality	Default	Conformance
2	Discriminator	uint16	max 4095			M
3	Iterations	uint32	1000 to 100000			M
4	Salt	octstr	16 to 32			M

11.25.7.6. TransferAnchorRequest Command

This command SHALL be sent by a candidate Joint Fabric Anchor Administrator to the current Joint Fabric Anchor Administrator to request transfer of the Anchor Fabric.

11.25.7.7. TransferAnchorResponse Command

This command SHALL be generated in response to the [Transfer Anchor Request](#) command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	StatusCode	TransferAnchorResponseStatusEnum				M

11.25.7.8. TransferAnchorComplete Command

This command SHALL indicate the completion of the transfer of the Anchor Fabric to another Joint Fabric Ecosystem Administrator.

11.25.7.9. AnnounceJointFabricAdministrator Command

This command SHALL be used for communicating to client the endpoint that holds the Joint Fabric Administrator Cluster.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EndpointID	endpoint-no	all			M

This field SHALL contain the unique identifier for the endpoint that holds the Joint Fabric Administrator Cluster.

11.26. Commissioner Control Cluster

The Commissioner Control Cluster supports the ability for clients to request the commissioning of themselves or other nodes onto a fabric which the cluster server can commission onto. An example use case is ecosystem to ecosystem [Fabric Synchronization setup](#).