

istrator Commissioning Cluster. Refer to the [OpenCommissioningWindow](#) command for a description of the command behavior and parameters.

The parameters for ReverseOpenCommissioningWindow command are as follows:

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Commissioning-Timeout	uint16	desc			M
1	PAKEPass-codeVerifier	octstr	97			M
2	Discriminator	uint16	max 4095			M
3	Iterations	uint32	1000 to 100000			M
4	Salt	octstr	16 to 32			M

11.26.7. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	CommissioningRequestResult	INFO		M S	M

11.26.7.1. CommissioningRequestResult Event

This event SHALL be generated by the server following a RequestCommissioningApproval command which the server responded to with SUCCESS.

NOTE

The approval is valid for a period determined by the manufacturer and characteristics of the node presenting the Commissioner Control Cluster. Clients SHOULD send the CommissionNode command immediately upon receiving a CommissioningRequestResult event.

Access Modifier: Fabric-Sensitive						
ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	RequestID	uint64	all			M
1	ClientNodeID	node-id	all			M
2	StatusCode	status	desc			M