

Anchor ICAC.

- c. request [ICA Cross Signing](#) from the new Joint Fabric Anchor Administrator discovered via Service Discovery ([Administrator](#) and [Anchor](#) flags are set in [JF TXT key](#)).
- d. remove devices from the fabric governed by the old [Anchor CA](#) using the [Section 11.18.6.12, “RemoveFabric”](#) command.
- e. start commissioning devices onto the Joint Fabric using the new ICAC for NOC issuance.

12.2.7. Administrator Removal

Since [Section 12.2, “Joint Fabric”](#) has multiple [Intermediate NOC Certificate Authorities](#) trusted by Joint Fabric Anchor CA, the following steps SHALL be taken to remove an [Intermediate NOC Certificate Authority](#) from a [Section 12.2, “Joint Fabric”](#).

The [Section 11.18.6.12, “RemoveFabric”](#) section outlines a [Warning](#) that SHALL apply here for removing a Joint Fabric Administrator.

1. Joint Fabric Anchor Administrator SHALL send a [Section 11.18.6.12, “RemoveFabric”](#) command to a Joint Fabric Admin that user has consented to remove.
2. Joint Fabric Administrator SHALL remove the outgoing Administrator from the Joint Fabric Datastore.
3. The outgoing Administrator SHALL remove the given Fabric and **delete all associated fabric-scoped data**.
4. Joint Fabric Anchor Administrator SHALL increase [Section 12.2.4.1, “Administrator CAT”](#) version and issue itself a new NOC.
5. Administrator B SHALL set new [NOC](#) for all the Joint Fabric Administrators.

12.2.7.1. Security Consideration

Matter does not currently include any method for a [Trusted Root Certificate](#) to revoke an ICAC previously issued. Thus, to ensure proper fail proof removal of a Joint Fabric Administrator from a Joint Fabric, the Anchor Administrator SHOULD trigger a transition to a new [Trusted Root Certificate](#) as described in the [Section 12.2.6, “Anchor Administrator Selection”](#) section. In this case, the new Anchor can be run by the same ecosystem as the old Anchor but the new [Trusted Root Certificate](#) will not issue an ICAC to the Joint Fabric Administrator that is to be removed.

12.3. User Consent

A user who wishes to have an already commissioned Node join another Fabric (and therefore another Security Domain) provides consent by instructing an existing Administrator, which SHALL put the Node into commissioning mode by using steps outlined in [Section 5.6.4, “Open Commissioning Window”](#). Administrators SHALL provide a mechanism for the user to thus instruct them.

12.4. Administrator-Assisted Commissioning Method

Administrators SHALL support opening a commissioning window on a Node using the mandatory