

- Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
- If the [associated fabric](#) for that matching entry, does not equal the [accessing fabric](#):
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
- Return that entry as the [Endpoint](#) field in the corresponding [FindEndpointResponse](#) command.

14.5.7.4. FindEndpointResponse Command

This command is used to report the result of the FindEndpoint command.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Endpoint	TLSEndpointStruct	0 to 65534			M

Endpoint Field

The field SHALL be a [TLSEndpointStruct](#) containing the requested entry.

14.5.7.5. RemoveEndpoint Command

This command is used to remove a TLS Endpoint by its ID.

This command SHALL be generated to request the Node remove any TLS Endpoint.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	EndpointID	TLSEndpointID	0 to 65534			M

EndpointID Field

This field SHALL represent the unique [TLSEndpointID](#) of the TLS Endpoint to remove.

Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If the [ProvisionedEndpoints](#) list is empty:
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.
- If there is no matching entry found for the passed in *EndpointID* in the [ProvisionedEndpoints](#) list:
 - Fail the command with the status code NOT_FOUND, and end processing with no other side effects.