

ID	Name	Direction	Response	Access	Conformance
0x00	AddGroup	client ⇒ server	AddGroupRe- sponse	M F	M
0x01	ViewGroup	client ⇒ server	ViewGroupRe- sponse	O F	M
0x02	GetGroup- Membership	client ⇒ server	GetGroupMem- ber- shipResponse	O F	M
0x03	RemoveGroup	client ⇒ server	Remove- GroupRe- sponse	M F	M
0x04	RemoveAll- Groups	client ⇒ server	Y	M F	M
0x05	AddGroupIfI- dentifying	client ⇒ server	Y	M F	M
0x00	AddGroupRe- sponse	client ⇐ server	N		M
0x01	ViewGroupRe- sponse	client ⇐ server	N		M
0x02	GetGroup- Member- shipResponse	client ⇐ server	N		M
0x03	Remove- GroupRe- sponse	client ⇐ server	N		M

1.3.7.1. AddGroup Command

The AddGroup command allows a client to add group membership in a particular group for the server endpoint.

ID	Name	Type	Constraint	Quality	Fallback	Confor- mance
0	GroupID	group-id	min 1			M
1	GroupName	string	max 16			M

1.3.7.1.1. GroupID Field

This field SHALL be used to identify the group and any associated key material to which the server endpoint is to be added.

1.3.7.1.2. GroupName Field

This field MAY be set to a human-readable name for the group. If the client has no name for the