

| ID   | Name                              | Direction       | Response                   | Access | Conformance |
|------|-----------------------------------|-----------------|----------------------------|--------|-------------|
| 0x00 | <b>AddScene</b>                   | client ⇒ server | AddSceneResponse           | M F    | M           |
| 0x00 | <b>AddSceneResponse</b>           | client ⇐ server | N                          |        | M           |
| 0x01 | <b>ViewScene</b>                  | client ⇒ server | ViewSceneResponse          | O F    | M           |
| 0x01 | <b>ViewSceneResponse</b>          | client ⇐ server | N                          |        | M           |
| 0x02 | <b>RemoveScene</b>                | client ⇒ server | RemoveSceneResponse        | M F    | M           |
| 0x02 | <b>RemoveSceneResponse</b>        | client ⇐ server | N                          |        | M           |
| 0x03 | <b>RemoveAllScenes</b>            | client ⇒ server | RemoveAllScenesResponse    | M F    | M           |
| 0x03 | <b>RemoveAllScenesResponse</b>    | client ⇐ server | N                          |        | M           |
| 0x04 | <b>StoreScene</b>                 | client ⇒ server | StoreSceneResponse         | M F    | M           |
| 0x04 | <b>StoreSceneResponse</b>         | client ⇐ server | N                          |        | M           |
| 0x05 | <b>RecallScene</b>                | client ⇒ server | Y                          | O F    | M           |
| 0x06 | <b>GetSceneMembership</b>         | client ⇒ server | GetSceneMembershipResponse | O F    | M           |
| 0x06 | <b>GetSceneMembershipResponse</b> | client ⇐ server | N                          |        | M           |
| 0x40 | <b>CopyScene</b>                  | client ⇒ server | CopySceneResponse          | M F    | O           |
| 0x40 | <b>CopySceneResponse</b>          | client ⇐ server | N                          |        | CopyScene   |

#### 1.4.9.1. Generic Usage Notes

The scene identifier 0, when used with group identifier 0, is reserved for the global scene used by the On/Off cluster.

#### 1.4.9.2. AddScene Command

This command is used to add a new scene.