

The following sections describe each feature in some detail. Further details are found within the specification.

#### 1.6.4.1. On/Off Feature

For many applications, a close relationship between this cluster and the On/Off cluster is needed. This section describes the dependencies that are required when an endpoint that implements this server cluster and also implements the On/Off server cluster. Before the On/Off feature bit in the FeatureMap existed, there was a dependency between this cluster and the On/Off cluster.

The OnOff attribute of the On/Off cluster and the CurrentLevel attribute of the Level Control cluster are intrinsically independent variables, as they are on different clusters. However, when both clusters are implemented on the same endpoint, dependencies MAY be introduced between them. Facilities are provided to introduce dependencies if required.

##### 1.6.4.1.1. Effect of On/Off Commands on the CurrentLevel attribute

The [OnLevel](#) attribute determines whether commands of the On/Off cluster have a permanent effect on the CurrentLevel attribute or not. If this attribute is defined (i.e., implemented and not equal to null) they do have a permanent effect, otherwise they do not. There is always a temporary effect, due to fading up / down.

The effect on the Level Control cluster on receipt of the various commands of the On/Off cluster are as detailed in the [Effect of On/Off Commands when associated with Level Control](#) table. In this table, and throughout this cluster specification, 'level' means the value of the CurrentLevel attribute.

*Table 2. Effect of On/Off Commands when associated with Level Control*

| Command | Action On Receipt                                                                                                                                                                                                               |
|---------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| On      | Temporarily store CurrentLevel.<br>Set CurrentLevel to the minimum level allowed for the device.<br>Change CurrentLevel to OnLevel, or to the stored level if OnLevel is not defined, over the time period OnOffTransitionTime. |
| Off     | Temporarily store CurrentLevel.<br>Change CurrentLevel to the minimum level allowed for the device over the time period OnOffTransitionTime.<br>If OnLevel is not defined, set the CurrentLevel to the stored level.            |
| Toggle  | If the OnOff attribute has the value FALSE, proceed as for the On command. Otherwise proceed as for the Off command.                                                                                                            |

Intention of the actions described in the table above is that CurrentLevel, which was in effect before any of the On, Off or Toggle commands were issued, SHALL be restored, after the transition is completed. If another of these commands is received, before the transition is completed, the originally stored CurrentLevel SHALL be preserved and restored.