

ID	Name	Direction	Response	Access	Conformance
0x00	SuppressAlarm	client ⇒ server	Y	O	SPRS
0x01	EnableDisableAlarm	client ⇒ server	Y	O	VIS AUD

1.8.7.1. SuppressAlarm Command

This command will suppress the alarm modes specified.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	AlarmsToSuppress	Alarm-ModeBitmap	all			M

1.8.7.1.1. AlarmsToSuppress Field

This field SHALL indicate the alarm modes to suppress.

1.8.7.1.2. Effect on Receipt

If any of the requested alarm modes are not supported this command SHALL be ignored and the server SHALL return an CONSTRAINT_ERROR status code.

If any of the requested alarm modes are not active, in case the sensor is not triggered or the alarm mode is disabled/not supported, this command SHALL be ignored and the server SHALL return an INVALID_IN_STATE status code.

In the case an alarm is already suppressed and the specific bit is set in the [AlarmsSuppressed](#) attribute, the bit SHALL be ignored and the remaining bits SHALL be evaluated.

For the valid bits in the AlarmsToSuppress field, the device SHALL suppress the specified alarm modes as requested in the AlarmsToSuppress field and set the [AlarmsSuppressed](#) attribute accordingly.

1.8.7.2. EnableDisableAlarm Command

This command allows setting the enable or disable value for the specified alarm modes.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Alarm- sToEnableDisable	Alarm-ModeBitmap	all			M

1.8.7.2.1. AlarmsToEnableDisable Field

This field SHALL indicate the alarm modes to either enable or disable depending on the bit status,