

device when the `OperationalState` attribute is populated with `Error`. See [Section 1.14.4.4, “ErrorStateStruct Type”](#) for general requirements on the population of this attribute.

When there is no error detected, this SHALL have an `ErrorStateID` of `NoError`.

1.14.6. Commands

ID	Name	Direction	Response	Access	Conformance
0x00	Pause	client ⇒ server	Operational-CommandResponse	O	Resume, O
0x01	Stop	client ⇒ server	Operational-CommandResponse	O	Start, O
0x02	Start	client ⇒ server	Operational-CommandResponse	O	O
0x03	Resume	client ⇒ server	Operational-CommandResponse	O	Pause, O
0x04	Operational-CommandResponse	client ⇐ server	N	O	Pause Stop Start Resume

Note that it is entirely possible due to regulatory or other reasons for an instance of this cluster to expose no possible commands. When that occurs, this cluster does not provide any ability to actuate the device, instead it provides readable (and by extension, can be subscribed to) information as to the state of the device only. The commands that are supported SHALL be exposed by the device in the `AcceptedCommandList` global attribute.

1.14.6.1. Pause Command

This command SHALL be supported if the device supports remotely pausing the operation. If this command is supported, the Resume command SHALL also be supported.

On receipt of this command, the device SHALL pause its operation if it is possible based on the current function of the server. For example, if it is at a point where it is safe to do so and/or permitted, but can be restarted from the point at which pause occurred.

If this command is received when already in the Paused state the device SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `NoError` but take no further action.

A device that receives this command in any state which is not Pause-compatible SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `CommandInvalidInState` and SHALL take no further action.