

1.14.6.3. Start Command

This command SHALL be supported if the device supports remotely starting the operation. If this command is supported, the 'Stop command SHALL also be supported.

On receipt of this command, the device SHALL start its operation if it is safe to do so and the device is in an operational state from which it can be started. There may be either regulatory or manufacturer-imposed safety and security requirements that first necessitate some specific action at the device before a Start command can be honored. In such instances, a device SHALL respond with a status code of `CommandInvalidInState` if a Start command is received prior to the required on-device action.

If this command is received when already in the Running state the device SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `NoError` but take no further action.

A device that is unable to honor the Start command for whatever reason SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `UnableToStartOrResume` but take no further action.

Otherwise, on success:

- The `OperationalState` attribute SHALL be set to `Running`.
- The device SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `NoError`.

1.14.6.4. Resume Command

This command SHALL be supported if the device supports remotely resuming the operation. If this command is supported, the Pause command SHALL also be supported.

On receipt of this command, the device SHALL resume its operation from the point it was at when it received the Pause command, or from the point when it was paused by means outside of this cluster (for example by manual button press).

If this command is received when already in the Running state the device SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `NoError` but take no further action.

A device that receives this command in any state which is not Resume-compatible SHALL respond with an [OperationalCommandResponse](#) command with an `ErrorStateID` of `CommandInvalidInState` and SHALL take no further action.

States are defined as Resume-compatible as follows:

- For states defined in this cluster specification, in [Table 4, “Resume Compatibility”](#).
- For states defined by derived cluster specifications, in the corresponding specifications.
- For manufacturer-specific states, by the manufacturer.

The following table defines the compatibility of this cluster’s states with the Resume command.