

NOTE

It is currently not specified where the friendly name label can be found on the node, meaning that clients SHOULD NOT rely on a certain method they happen to observe in a particular server instance, since other instances could employ a different method.

The device SHOULD make it possible for the user to view which nodes have access to this cluster and to individually remove privileges for each node.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	MessageID	MessageID	all			M
1	Priority	MessagePriorityEnum				M
2	Message-Control	MessageControlBitmap				M
3	StartTime	epoch-s		X		M
4	Duration	uint64	all	X		M
5	Message-Text	string	max 256			M
6	Responses	list[MessageResponseOptionStruct]	max 4			RESP

1.16.7.1.1. MessageID Field

This field SHALL indicate a globally unique ID for this message. See [MessageID](#).

1.16.7.1.2. Priority Field

This field SHALL indicate the priority level for this message. See [Priority](#).

1.16.7.1.3. MessageControl Field

This field SHALL indicate control information related to the message. See [MessageControl](#).

1.16.7.1.4. StartTime Field

This field SHALL indicate the time in UTC at which the message becomes available to be presented. A null value SHALL indicate "now." See [StartTime](#).

1.16.7.1.5. Duration Field

This field SHALL indicate the amount of time, in milliseconds, after the [StartTime](#) during which the message is available to be presented. A null value SHALL indicate "until changed". See [Duration](#).