

1.16.7.1.6. MessageText Field

This field SHALL indicate a string containing the message to be presented. See [MessageText](#).

1.16.7.1.7. Responses Field

This field SHALL indicate a list of potential responses to the message. The entries in this list SHALL have unique values of MessageResponseID.

If the [ResponseRequired](#) bit is set on the message but this list is empty, the device SHALL provide a generic acknowledgement button, e.g. "OK".

If the [ResponseRequired](#) bit is not set on the message, this list SHALL be ignored.

See [Responses](#).

1.16.7.2. CancelMessagesRequest Command

This command will cancel the message IDs specified.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	MessageIDs	list[MessageID]	max 8			M

1.16.7.2.1. MessageIDs Field

This field SHALL indicate the [MessageIDs](#) for the messages being cancelled.

Cancelling a message SHALL cause it to be removed from [Messages](#), cause its [MessageID](#) to be removed from [ActiveMessageIDs](#) and cause any active presentation of the message to cease.

Message IDs in this command that indicate messages that do not exist in [Messages](#), or that are not scoped to the fabric of the sender, SHALL be ignored.

1.16.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	Message-Queued	INFO		V	M
0x01	MessagePresented	INFO		V	M
0x02	MessageComplete	INFO		V	M

1.16.8.1. MessageQueued Event

This event SHALL be generated when a message is added to the [messages](#) attribute.