

#### 1.17.5.5.1. AreaID Field

This field SHALL indicate the identifier of the area, and the identifier SHALL be an entry in the SupportedAreas attribute's list.

#### 1.17.5.5.2. Status Field

This field SHALL indicate the operational status of the device regarding the area indicated by the AreaID field.

#### 1.17.5.5.3. TotalOperationalTime Field

This field SHALL indicate the total operational time, in seconds, from when the device started to operate at the area indicated by the AreaID field, until the operation finished, due to completion or due to skipping, including any time spent while paused.

A value of null indicates that the total operational time is unknown.

There MAY be cases where the total operational time exceeds the maximum value that can be conveyed by this attribute, and in such instances this attribute SHALL be populated with null.

This attribute SHALL be null if the Status field is not set to Completed or Skipped.

#### 1.17.5.5.4. EstimatedTime Field

This field SHALL indicate the estimated time for the operation, in seconds, from when the device will start operating at the area indicated by the AreaID field, until the operation completes, excluding any time spent while not operating in the area.

A value of null indicates that the estimated time is unknown. If the estimated time is unknown, or if it exceeds the maximum value that can be conveyed by this attribute, this attribute SHALL be null.

After initializing the [ProgressStruct](#) instance, the server SHOULD NOT change the value of this field, except when repopulating the entire instance, to avoid excessive reporting of the Progress attribute changes.

#### 1.17.5.6. OperationalStatusEnum Type

This data type is derived from enum8.

The following table defines the status values.

| Value | Name           | Summary                                                                                                                                              | Conformance |
|-------|----------------|------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|
| 0x00  | <b>Pending</b> | The device has not yet started operating at the given area, or has not finished operating at that area but it is not currently operating at the area | M           |