

| ID     | Name                    | Type                                   | Constraint | Quality | Fallback | Access | Conformance   |
|--------|-------------------------|----------------------------------------|------------|---------|----------|--------|---------------|
| 0x0001 | <b>SupportedMaps</b>    | list[ <a href="#">MapStruct</a> ]      | max 255    |         | MS       | R V    | MAPS          |
| 0x0002 | <b>SelectedAreas</b>    | list[uint32]                           | desc       |         | empty    | R V    | M             |
| 0x0003 | <b>CurrentArea</b>      | uint32                                 | desc       | X       | null     | R V    | desc          |
| 0x0004 | <b>EstimatedEndTime</b> | epoch-s                                |            | Q X     | null     | R V    | [CurrentArea] |
| 0x0005 | <b>Progress</b>         | list[ <a href="#">ProgressStruct</a> ] | max 255    |         | empty    | R V    | PROG          |

### 1.17.6.1. SupportedAreas Attribute

This attribute SHALL contain the list of areas that can be included in the SelectedAreas attribute's list. Each item in this list represents a unique area, as indicated by the AreaID field of [AreaStruct](#).

Each entry in this list SHALL have a unique value for the AreaID field.

If the SupportedMaps attribute is not empty, each entry in this list SHALL have a unique value for the combination of the MapID and AreaInfo fields.

If the SupportedMaps attribute is empty, each entry in this list SHALL have a unique value for the AreaInfo field and SHALL have the MapID field set to null.

An empty value indicates that the device is currently unable to provide the list of supported areas.

#### NOTE

due to the maximum size of this list and to the fact that the entries MAY include strings (see LocationName), care must be taken by implementers to avoid creating a data structure that is overly large, which can result in significant latency in accessing this attribute.

The value of this attribute MAY change at any time via an out-of-band interaction outside of the server, such as interactions with a user interface, or due to internal device changes.

When removing entries in the SupportedAreas attribute list the server SHALL adjust the values of the SelectedAreas, CurrentArea, and Progress attributes such that they only reference valid entries in the updated SupportedAreas attribute list. These changes to the SelectedAreas, CurrentArea, and Progress attributes MAY result in the server setting some or all of them to empty (for SelectedAreas and Progress) or null (for CurrentArea), or updating them with data that matches the constraints from the description of the respective attributes. These actions are required to ensure having a consistent representation of the maps and locations available to the clients.

The SupportedAreas attribute list changes mentioned above SHOULD NOT be allowed while the device is operating, to reduce the impact on the clients, and the potential confusion for the users.