

server removing entries from the SupportedAreas attribute list. See the SupportedAreas attribute description for the implications of changing that attribute.

The SupportedMaps attribute list changes mentioned above SHOULD NOT be allowed while the device is operating, to reduce the impact on the clients, and the potential confusion for the users.

1.17.6.3. SelectedAreas Attribute

This attribute SHALL indicate the set of areas where the device SHOULD attempt to operate.

The mobile devices MAY travel without operating across any areas while attempting to reach the areas indicated by the SelectedAreas attribute. For example, a robotic vacuum cleaner MAY drive without cleaning when traveling without operating.

If this attribute is empty, the device is not constrained to operate in any specific areas.

If this attribute is not empty:

- each item in this list SHALL match the AreaID field of an entry in the SupportedAreas attribute's list
- each entry in this list SHALL have a unique value

1.17.6.4. CurrentArea Attribute

If the device is mobile, this attribute SHALL indicate the area where the device is currently located, regardless of whether it is operating or not, such as while traveling between areas.

If the device is not mobile and can operate at multiple areas sequentially, this attribute SHALL indicate the area which is currently being serviced, or the area which is currently traversed by the device. For example, a camera device MAY use this attribute to indicate which area it currently takes video of (serviced area) or which area it currently has in view but not taking video of (e.g. an area which is traversed while panning).

NOTE

A device MAY traverse an area regardless of the status of the area (pending, skipped, or completed).

If a device can simultaneously operate at multiple areas, such as in the case of a sensor that can monitor multiple areas at the same time, the CurrentArea attribute SHALL NOT be implemented, since it doesn't apply. Else this attribute SHALL be optionally implemented.

A null value indicates that the device is currently unable to provide this information. For example, the device is traversing an unknown area, or the SupportedAreas attribute was updated and the area where the device is located was removed from that list.

If not null, the value of this attribute SHALL match the AreaID field of an entry on the SupportedAreas attribute's list.

1.17.6.5. EstimatedEndTime Attribute

This attribute SHALL represent the estimated Epoch time for completing operating at the area indi-