

2.14.6.7. TwoDCartesianMax Attribute

This attribute SHALL specify the maximum X and Y points that are allowed for TwoD Cartesian Zones. If this cluster is on the same endpoint as [Camera AV Stream Management Cluster](#), these values SHALL be equal to the value of [SensorWidth - 1](#) and [SensorHeight - 1](#) from the [VideoSensor-Params attribute](#).

2.14.7. Commands

ID	Name	Direction	Response	Access	Quality	Conformance
0x00	CreateTwoDCartesianZone	client ⇒ server	CreateTwoDCartesianZoneResponse	M		TWODCART & USERDEFINED
0x01	CreateTwoDCartesianZoneResponse	client ⇐ server	N			TWODCART & USERDEFINED
0x02	UpdateTwoDCartesianZone	client ⇒ server	Y	M		TWODCART & USERDEFINED
0x03	RemoveZone	client ⇒ server	Y	M		USERDEFINED
0x04	CreateOrUpdateTrigger	client ⇒ server	Y	M		M
0x05	RemoveTrigger	client ⇒ server	Y	M		M

2.14.7.1. CreateTwoDCartesianZone Command

This command SHALL create and store a TwoD Cartesian Zone.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	Zone	TwoDCartesianZoneStruct				M

2.14.7.1.1. Zone Field

The Zone field SHALL be a [TwoDCartesianZoneStruct](#) representing all information required to define the TwoD Cartesian Zone.