

- If the [Zone use](#) for that entry is not [Motion Value](#):
 - Fail the command with the status code `CONSTRAINT_ERROR`, and end processing with no other side effects.
- Add or update the passed in *Trigger* entry in the [Triggers](#) attribute.

2.14.7.6. RemoveTrigger Command

This command SHALL remove the Trigger for the provided ZoneID.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ZoneID	ZoneID				M

2.14.7.6.1. ZoneID Field

The ZoneID field SHALL be a [ZoneID](#) of the Zone Trigger to be removed.

2.14.7.6.2. Effect on Receipt

The following process SHALL be followed when the server receives this command:

- If no entry can be found for the passed in *ZoneID* in the [Triggers](#) attribute:
 - Fail the command with the status code `NOT_FOUND`, and end processing with no other side effects.
- Remove the entry associated with *ZoneID* from the [Triggers](#) attribute.

2.14.8. Events

ID	Name	Priority	Quality	Access	Conformance
0x00	ZoneTriggered	INFO		V	M
0x01	ZoneStopped	INFO		V	M

2.14.8.1. ZoneTriggered Event

This event SHALL be generated when a Zone is first triggered.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0x0000	Zone	ZoneID	all			M
0x0001	Reason	ZoneEvent-TriggeredReasonEnum	all			M