

4.2.6.1.4. RemotePressure Bit

If this bit is set, EffectiveControlMode is ConstantPressure and the setpoint for the pump is interpreted as a percentage of the range of the remote sensor ([MinMeasuredValue – MaxMeasuredValue]).

4.2.6.1.5. RemoteFlow Bit

If this bit is set, EffectiveControlMode is ConstantFlow, and the setpoint for the pump is interpreted as a percentage of the range of the remote sensor ([MinMeasuredValue – MaxMeasuredValue]).

4.2.6.1.6. RemoteTemperature Bit

If this bit is set, EffectiveControlMode is ConstantTemperature, and the setpoint for the pump is interpreted as a percentage of the range of the remote sensor ([MinMeasuredValue – MaxMeasuredValue]).

4.2.6.2. OperationModeEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0	Normal	The pump is controlled by a setpoint, as defined by a connected remote sensor or by the ControlMode attribute.	M
1	Minimum	This value sets the pump to run at the minimum possible speed it can without being stopped.	SPD
2	Maximum	This value sets the pump to run at its maximum possible speed.	SPD
3	Local	This value sets the pump to run with the local settings of the pump, regardless of what these are.	LOCAL

4.2.6.2.1. Normal Value

If the pump is running in this operation mode the setpoint is an internal variable which MAY be controlled between 0% and 100%, e.g., by means of the Level Control cluster