

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x004A	NumberOfPresets	uint8	min 1	F		R V	PRES
0x004B	NumberOfSchedules	uint8	min 1	F		R V	MSCH
0x004C	NumberOfScheduleTransitions	uint8	min 1	F		R V	MSCH
0x004D	NumberOfScheduleTransitionPerDay	uint8	min 1	F X		R V	MSCH
0x004E	ActivePresetHandle	octstr	max 16	N X		R V	PRES
0x004F	ActiveScheduleHandle	octstr	max 16	N X		R V	MSCH
0x0050	Presets	list[PresetStruct]	max NumberOfPresets	N T		RW VM	PRES
0x0051	Schedules	list[ScheduleStruct]	max NumberOfSchedules	N T		RW VM	MSCH
0x0052	SetpointHoldExpiryTimestamp	epoch-s	all	XN	null	R V	O

4.3.9.1. Calculated Local Temperature

The local temperature SHALL be calculated from the *measured temperature*, including any adjustments applied by [LocalTemperatureCalibration](#) attribute (if any) as follows:

$$\text{Calculated Local Temperature} = (\text{measured temperature}) + \text{LocalTemperatureCalibration}$$