

4.3.9.19. MinCoolSetpointLimit Attribute

This attribute SHALL indicate the minimum level that the cooling setpoint MAY be set to.

Refer to [Setpoint Limits](#) for constraints. If an attempt is made to set this attribute to a value which conflicts with setpoint values then those setpoints SHALL be adjusted by the minimum amount to permit this attribute to be set to the desired value. If an attempt is made to set this attribute to a value which is not consistent with the constraints and cannot be resolved by modifying setpoints then a response with the status code CONSTRAINT_ERROR SHALL be returned.

4.3.9.20. MaxCoolSetpointLimit Attribute

This attribute SHALL indicate the maximum level that the cooling setpoint MAY be set to.

Refer to [Setpoint Limits](#) for constraints. If an attempt is made to set this attribute to a value which conflicts with setpoint values then those setpoints SHALL be adjusted by the minimum amount to permit this attribute to be set to the desired value. If an attempt is made to set this attribute to a value which is not consistent with the constraints and cannot be resolved by modifying setpoints then a response with the status code CONSTRAINT_ERROR SHALL be returned.

4.3.9.21. MinSetpointDeadBand Attribute

On devices which support the AUTO feature, this attribute SHALL indicate the minimum difference between the Heat Setpoint and the Cool Setpoint.

Refer to [Setpoint Limits](#) for constraints.

NOTE	Prior to revision 8 of this cluster specification the value of this attribute was constrained to a range of 0°C to 2.5°C.
NOTE	For backwards compatibility, this attribute is optionally writeable. However any writes to this attribute SHALL be silently ignored.

4.3.9.22. RemoteSensing Attribute

This attribute SHALL indicate when the local temperature, outdoor temperature and occupancy are being sensed by remote networked sensors, rather than internal sensors.

If the LTNE feature is present in the server, the LocalTemperature RemoteSensing bit value SHALL always report a value of 0.

If the LocalTemperature RemoteSensing bit is written with a value of 1 when the LTNE feature is present, the write SHALL fail and the server SHALL report a CONSTRAINT_ERROR.

4.3.9.23. ControlSequenceOfOperation Attribute

This attribute SHALL indicate the overall operating environment of the thermostat, and thus the possible system modes that the thermostat can operate in.

If an attempt is made to write to this attribute, the server SHALL silently ignore the write and the