

value of this attribute SHALL remain unchanged. This behavior is in place for backwards compatibility with existing thermostats.

4.3.9.24. SystemMode Attribute

This attribute SHALL indicate the current operating mode of the thermostat. Its value SHALL be limited by the [ControlSequenceOfOperation](#) attribute.

4.3.9.25. ThermostatRunningMode Attribute

This attribute SHALL indicate the running mode of the thermostat. This attribute uses the same values as [SystemModeEnum](#) but can only be Off, Cool or Heat. This attribute is intended to provide additional information when the thermostat's system mode is in auto mode.

4.3.9.26. StartOfWeek Attribute

This attribute SHALL indicate the day of the week that this thermostat considers to be the start of week for weekly setpoint scheduling.

This attribute MAY be able to be used as the base to determine if the device supports weekly scheduling by reading the attribute. Successful response means that the weekly scheduling is supported.

4.3.9.27. NumberOfWeeklyTransitions Attribute

This attribute SHALL indicate how many weekly schedule transitions the thermostat is capable of handling.

4.3.9.28. NumberOfDailyTransitions Attribute

This attribute SHALL indicate how many daily schedule transitions the thermostat is capable of handling.

4.3.9.29. TemperatureSetpointHold Attribute

This attribute SHALL indicate the temperature hold status on the thermostat. If hold status is on, the thermostat SHOULD maintain the temperature setpoint for the current mode until a system mode change. If hold status is off, the thermostat SHOULD follow the setpoint transitions specified by its internal scheduling program. If the thermostat supports setpoint hold for a specific duration, it SHOULD also implement the [TemperatureSetpointHoldDuration](#) attribute.

If the server supports a setpoint hold for a specific duration, it SHOULD also implement the [SetpointHoldExpiryTimestamp](#) attribute.

If this attribute is updated to SetpointHoldOn and the [TemperatureSetpointHoldDuration](#) has a non-null value and the [SetpointHoldExpiryTimestamp](#) is supported, the server SHALL update the [SetpointHoldExpiryTimestamp](#) with a value of current UTC timestamp, in seconds, plus the value in [TemperatureSetpointHoldDuration](#) multiplied by 60.

If this attribute is updated to SetpointHoldOff and the [SetpointHoldExpiryTimestamp](#) is supported, the server SHALL set the [SetpointHoldExpiryTimestamp](#) to null.