

Value	Name	Summary	Conformance
2	Transitioning	Valve is transitioning between closed and open positions or between levels	M

4.6.6. Status Codes

4.6.6.1. StatusCodeEnum Type

This data type is derived from enum8.

Value	Name	Summary	Conformance
0x02	FailureDueToFault	The requested action could not be performed due to a fault on the valve.	M

4.6.7. Attributes

ID	Name	Type	Constraint	Quality	Fallback	Access	Conformance
0x0000	Open-Duration	elapsed-s	min 1	X		R V	M
0x0001	Default-Open-Duration	elapsed-s	min 1	N X		RW VO	M
0x0002	AutoClose-Time	epoch-us	all	X		R V	TS
0x0003	RemainingDuration	elapsed-s	all	Q X		R V	M
0x0004	CurrentState	ValveStateEnum	all	X		R V	M
0x0005	Target-State	ValveStateEnum	all	X		R V	M
0x0006	CurrentLevel	percent	all	X		R V	LVL
0x0007	TargetLevel	percent	all	X		R V	LVL
0x0008	Default-OpenLevel	percent	1 to 100	N	100	RW VO	[LVL]