

4.6.9.2. ValveFault Event

This event SHALL be generated when the valve registers or clears a fault, e.g. not being able to transition to the requested target level or state.

ID	Name	Type	Constraint	Quality	Fallback	Conformance
0	ValveFault	ValveFault- Bitmap	all			M

4.6.9.2.1. ValveFault Field

This field SHALL indicate the value of the [ValveFault](#) attribute, at the time this event is generated.