

5.2.6.14. OperationErrorEnum Type

This data type is derived from enum8.

This enumeration SHALL indicate the error cause of the Lock/Unlock operation performed.

Value	Name	Summary	Conformance
0	Unspecified	Lock/unlock error caused by unknown or unspecified source	O
1	InvalidCredential	Lock/unlock error caused by invalid PIN, RFID, fingerprint or other credential	USR
2	DisabledUserDenied	Lock/unlock error caused by disabled USER or credential	M
3	Restricted	Lock/unlock error caused by schedule restriction	WDSCH YDSCH
4	InsufficientBattery	Lock/unlock error caused by insufficient battery power left to safely actuate the lock	O

5.2.6.15. OperatingModeEnum Type

This data type is derived from enum8.

This enumeration SHALL indicate the lock operating mode.

Value	Name	Summary	Conformance
0	Normal		M
1	Vacation		O
2	Privacy		O
3	NoRemoteLockUnlock		M
4	Passage		O

The table below shows the operating mode and which interfaces are enabled, if supported, for each mode.

Name	Keypad*	Remote*	RFID*
Normal	Y	Y	Y
Vacation	N	Y	N