

rent Sound Volume setting on the server, the client SHOULD read/write to the Sound Volume attribute.

5.2.9.26.1. LocalProgramming Bit

This bit SHALL indicate the default value of the EnableLocalProgramming attribute.

5.2.9.26.2. KeypadInterface Bit

This bit SHALL indicate the default state of the keypad interface.

5.2.9.26.3. RemoteInterface Bit

This bit SHALL indicate the default state of the remote interface.

5.2.9.26.4. SoundVolume Bit

This bit SHALL indicate the default value of SoundVolume attribute.

5.2.9.26.5. AutoRelockTime Bit

This bit SHALL indicate the default value of AutoRelockTime attribute.

5.2.9.26.6. LEDSettings Bit

This bit SHALL indicate the default value of LEDSettings attribute.

5.2.9.27. EnableLocalProgramming Attribute

This attribute SHALL enable/disable local programming on the door lock of certain features (see LocalProgrammingFeatures attribute). If this value is set to TRUE then local programming is enabled on the door lock for all features. If it is set to FALSE then local programming is disabled on the door lock for those features whose bit is set to 0 in the LocalProgrammingFeatures attribute. Local programming SHALL be enabled by default.

5.2.9.28. EnableOneTouchLocking Attribute

This attribute SHALL enable/disable the ability to lock the door lock with a single touch on the door lock.

5.2.9.29. EnableInsideStatusLED Attribute

This attribute SHALL enable/disable an inside LED that allows the user to see at a glance if the door is locked.

5.2.9.30. EnablePrivacyModeButton Attribute

This attribute SHALL enable/disable a button inside the door that is used to put the lock into privacy mode. When the lock is in privacy mode it cannot be manipulated from the outside.